

# ERA

## 830-12 PVCu Snaplock Fitting Instructions

### Installing a PVCu Snaplock (keyless)

To fit a PVCu Snaplock you will require the following tools:

- Drill
- 1.5mm drill bit
- Posidriv screwdriver

(Please ensure screws enclosed are suitable for application prior to use).

- A** From the inside of your house, close the window and select the correct position for the PVCu Snaplock on the outward opening frame:
- ◀ Position if fitting with a single lock
  - ◀ Position if fitting with two locks
- B** Drill pilot holes using the PVCu Snaplock as a template. Drill through the frame and the inside wall of the frame. If you encounter a reinforced steel or aluminium section, drill through that section carefully as to not touch the glass. Fix the PVCu Snaplock to the frame using suitable screws to ensure a tight fit. Once done, push the plastic screw cover over the screw head holes with a gentle push-fit.
- C** To ensure a tight fit of the finger to the frame when in the locked position, select a pad from those provided and press the pad into the hole provided in the finger. Take care that the fit is not so tight as to mark the PVCu frame.

### Additional Information

**Operation** - Swing the finger over the fixed frame to stop the window opening. To free the window open, swing the finger back over the fixed base.

**Maintenance** - Use a moist cloth only to clean all types of finish, household abrasives or solvents may affect the surface finish - lubrication may occasionally be required.

